

EcoFlush[™]





Change flush volumes

Remember that flush buttons should not be hold, just pushed once quick. Owner is responishbe for correct flush volumes.





















IMPORTANT ABOUT FLUSH VOLUMES

The flush volumes of EcoFlush is factory set at 2.5 / 0.3 liters. These volumes applies if the flush button is pressed distinctive for about 1 second. If the buttons are pressed longer more flushing water will be used. It is the user's responsibility to not use too much water for flushing and that only the small flush is used when only urination. EcoFlush does not guarantee low flush volumes, but provides the opportunity for this at the correct use. EcoFlush average of 0.8 liters of water per flush is calculated when using 5 small flushes + 1 large flush per day. See the user guide for changing the flush volumes.









Clean the urine outlet regularly for best longtime maintenance.







